BRIGHT - TECK CONCENTRATED TEAK BRIGHTENER 2ND STAGE

BRIGHT TECK has a very powerful penetrating action for the second stage in the restoration of a teak deck.

BRIGHT TECK should be used immediately after the teak cleaner SUN TECK.

BRIGHT TECK is a controlled acid-based product which uses a combination of active substances to restore teak decks to their original colour.

BRIGHT TECK does not affect in any way the caulking, fibreglass and paint when the advise usage are respected.

BRIGHT TECK removes greyish stains cause by severe weather, salt water and pollution, restoring the teak to its natural colour.

BRIGHT TECK is used as follows :

- Dilute 1 litre of product for 3 to 5 litres of water depending on the level of staining.
- Wet teak and apply dilution evenly with a soft brush.
- Leave for 10 to 15 minutes.
- Do not rub.
- Rinse abundantly with a water jet.

Coverage for 1 litre of product : 5 to 7 m^2 .

IMPORTANT: Keep out of reach of children. R36/38 Irritant for eyes and skin. S26 : In the event of contact with eyes, rinse immediately and abundantly with clear water at least 15 minutes. If irritations persist, consult a doctor. S37 : Wear protective gloves. Always make beforehand, a test with the surface to be treated to determine the compatibility and the time of contact suited. Components contain less than 5 % of anionic surfactants and 5 % or over but less than 15 % of non- ionic surfactants

